




FIL CEILING SURFACE

INSTALLATION INSTRUCTIONS | SEPTEMBER 2023




DIMENSIONS



MOUNTING INSTRUCTION


- 1 Remove the mounting base by loosening the socket screws and fix it to the ceiling with screws (screws are not included).
- 2 Guide the luminaire cable through the rod. There is a nylon thread attached in the rod, which is an auxiliary tool to help the user to pull the cable through the pole.
- 3 Tighten the two screws near the lower end of the pole to fix the luminaire and the rod (screws are included).
- 4 Tighten the four screws in the mounting base to fix the rod on the mounting base (screws are included).
- 5 **POWER CONNECTION**
Connect to 220-240V.
- 6 Fix the cover to the mounting base with the socket screws.



PB19-010-835-00_v0

FIL CEILING SURFACE

INSTALLATION INSTRUCTIONS | SEPTEMBER 2023




DISMOUNTING AND RECYCLING INSTRUCTIONS

Light source & driver

- 1 Loosen the socket screws and remove the lip from the ceiling base.
- 2 Disconnect the wires and unscrew the driver.
- 3 Loosen the screws and remove the luminaire from the ceiling base.
- 4 Pull out the end cap from the end of the luminaire with a handy tool then remove the grid brackets by pulling.
- 5 Remove the diffuser.
- 6 Remove the light source.



The driver can be replaced by the end user.



The light source is replaceable by an authorized professional.
For advice contact your Wever & Ducré customer service contact point.



This luminaire contains a light source with the energy class E.