


BLIEK ROUND

INSTALLATION INSTRUCTIONS | MAY 2021




MOUNTING INSTRUCTION

- 1 Make a hole in the ceiling according to the prescribed dimensions.


2 POWER CONNECTION

LED Always use a driver according to the specifications of the LED module.

Single connection



Multiple connection



PAR16

Single connection



Multiple connection



- 3 Push the springs up and insert the fixture in the ceiling hole.

DIMENSIONS

1.0 LED with wire springs		126-130	75	4-25
1.0 PAR16 with wire springs		126-130	75	4-25
1.0 LED with blade springs		127	75	Min4
1.0 PAR16 with blade springs		127	75	Min4



Driver must be powered off before connecting cables.

Before connecting the luminaire/LED module to the driver please make sure the driver is not powered but disconnected from the mains. The driver can only be powered when the luminaire/LED module is already connected. Disregarding this instruction might damage or even destroy the luminaire/LED module.

