

KIOSK FLOOR

INSTALLATION INSTRUCTIONS | OCTOBER 2023



WEVER & DUCRÉ

DIMENSIONS



MOUNTING INSTRUCTION


- Dismount the pole, connector and spike.
- 2 Unscrew the socket screw from the pole.
- 3 Guide the cable through the pole and insert the LED module into the pole by pushing.
- 4 Pull the cable through the connector and screw the connector back to the pole.
- **5** Fix the spike (or optional fixation plate) to the connector with the screws.
- 6 Make sure to align the slot with the hole and fix the socket screw again.


7 POWER CONNECTION

Connect to 220-240V. Connect the wires with the waterproof connectors. Please see the detailed method in the separate instruction sheet of the waterproof connection.

KIOSK FLOOR

INSTALLATION INSTRUCTIONS | OCTOBER 2023







DISMOUNTING AND RECYCLING INSTRUCTIONS

Light source & driver

1 Unscrew the socket screw and pull out the fixture from the pole.

2 Break the glass.

Remove the reflector(s) and light source(s) by unscrewing it/them

4 Unscrew the metal sheets and disconnect the wires to remove



The light source is not replaceable.



The driver is not replaceable.



This luminaire contains a light source with the energy class D.