




TRAIN



INSTALLATION INSTRUCTIONS | MAY 2022



| | A | B | C |
|--|---|--|---|
| <p>use pin to make hole, not a knife</p> | | | |
| CABLE | | | |
| TYPE | ROUND H05RN-F H07RN8-F H07RN-F | ROUND H05RN-F | ROUND |
| OUTSIDE Ø | min 6.8mm max 8.9mm | min 5mm max 6.8mm | min 1.5mm max 2.6mm |
| CONDUCTION SECTION | 2or3x 0.75mm ² 2or3x 1.0mm ² 2or3x 1.5mm ² | 2or3x 0.75mm ² 2x 1.0mm ² | 0.75mm ² 1.5mm ² |




DIMENSIONS



MOUNTING INSTRUCTION

- 1 Remove the mounting base from the luminaire by loosening the side screws and mount it on the wall with screws (screws are not included).

- 2 POWER CONNECTION
Connect to 220-240V.




Connect the earth cable.



Please use a matching grommet based on the used 220-240V cable and the corresponding type in the overview table.

for example:



Push the grommet into the back plate.

Pull the cable through the back plate.

Mount the back plate on the wall.

- 3 Fix the luminaire on the base with the side screws.

PB19-010-547-00_v3





WEVER & DUCRÉ
LIGHTING

WEVER & DUCRÉ BV
Spinnerijstraat 99/21, 8500 Kortrijk, Belgium
weverducre.com

TRAIN

INSTALLATION INSTRUCTIONS | MAY 2022




DISMOUNTING INSTRUCTIONS

Light source

- 1 Loosen the side screws, disconnect wires, and remove the fixture from the mounting base.
- 2 Break the glass.
- 3 Take out the components and the light source.

The light source is not replaceable.



This luminaire contains a light source with the energy class F.

