



# SFERA PORTABLE

CM14142 S - PC1271

### INSTALLATION MANUAL

#### **SFERA**

Floor light, Table light



### COMPONENTS INCLUDED WITH UNIT:

1x assembled light

- 1x charging cable USB C
- 1x pair cotton gloves
- 1x installation manual

#### **WARNING:**

The manufacturer assumes no liability for damage resulting from incorrect handling or use. When unpacking the light, do so with regard for its material composition – part is made of glass.

The light must be charged before first use.

Wear the cotton gloves included with the light when unpacking and assembling it.

Installation time: 5 minutes / 1 person



BROKIS S.R.O. ŠPANIELOVA 1315/25 163 00 PRAHA 6 - ŘEPY CZECH REPUBLIC ORG. ID 64940799 VAT ID CZ64940799 C 42174 MĚSTSKÝ SOUD V PRAZE

TEL +420 567 211 517 TECHNICAL@BROKIS.CZ INFO@BROKIS.CZ WWW.BROKIS.CZ

## INSTALLATION MANUAL

#### **SFERA**

Floor light, Table light



#### **CLEANING THE GLASS:**

BROKIS upholds only the highest possible quality standards. Prior to shipping, each light undergoes several quality controls and stages of cleaning. Because transportation, storage, and the amount of time that passes between packing at our plant and subsequent unpacking by the client can affect the light in different ways, we strongly recommend cleaning it prior to assembly.

The glass must first be rinsed in warm water, and a dish detergent may be used to remove all foreign particles, dust, and grease. Repeat the process if necessary and then dry the glass thoroughly with a paper towel.

Recommendation: Do not use mineral spirits, highly concentrated thinners, or other substances not intended for use on glass surfaces. Do not use any cleaning agents containing silicone, as they may leave a film and attract dust and smudges.

PRIOR TO SHIPPING, THE FUNCTIONALITY OF THE LIGHT AND ITS COMPONENTS ARE CHECKED THOROUGHLY. THE MANUFACTURER ASSUMES NO LIABILITY FOR THE MISHANDLING OF PRODUCTS.




#### 1. SWITCHING THE LIGHT ON AND OFF / DIMMING

Switch the light on and ensure it works properly.

Switch the light on and off by touching the metal button on its side. The same button is used to adjust the brightness of the light.

WARNING: TO AVOID DAMAGE TO THE BUTTON, DO NOT PUSH IT WITH FORCE BUT ONLY TOUCH IT LIGHTLY.




#### 2. CHARGING THE LIGHT USING THE USB-C CABLE

Use the provided USB-C cable to charge the light by inserting it into the connector on the light. When the light is charging, the LED shines red. When charging is complete, the LED changes to green.

Time to full charge: 4 hours

Battery life from full charge: 6 hours Recommended charging adapter: 5V / 2A max.



#### 3. INDUCTION (WIRELESS) CHARGING

Place the light on the induction charger. When the light is charging, the LED shines red. When charging is complete, the LED changes to green.

INDUCTION CHARGER NOT INLCUDED.

#### Illustration picture.

